



Nozzle Holders Warning Sheet (ZVP-PC-0162-00)



! WARNING! READ BELOW INFORMATION BEFORE USING BLAST HOSE NOZZLE HOLDERS

- 1.0 Always ensure that the blast hose being utilized is manufactured with a premium quality virgin rubber inner liner, ozone protective outer casing and is manufactured to dissipate static build up.
- 2.0 The blast hose should be adequately sized for the abrasive blasting application to ensure minimal pressure loss, and have a working pressure for its intended use.
- 3.0 When in use, lay the blast hose out as flat as possible and avoid sharp turns, coils or bends in the blast hose.
- 4.0 Ensure that the blast hose nozzle holders being utilized are of the correct size and specification to match the outer diameter of the blast hose.
- 5.0 Prior to fitting nozzle holders ensure that the end of the blasting hose is cut as square as possible to ensure the hose end fits squarely against the internal shoulder of the nozzle holder.
- 6.0 Blast hose nozzle holders are supplied with the correct quantity and size of nozzle holder attachment screws for affixing the nozzle holders to the blasting hose, only use the nozzle holder screws as supplied to avoid premature wear to the blast hose and nozzle holder.
- 7.0 Ensure that all blast hose nozzle holders are fitted with the correctly sized nozzle washer to suit / match the throat entry size of the blast nozzle being used.
- 8.0 Periodically inspect the nozzle holder for any signs of wear, air leakage, and ensure the nozzle holder threads are in good condition to securely hold the blast nozzle.